


## Important: Professional installation for the solution based on USB-Modules


This guide should help you to install the USB module. The HP printers of the newer generation are extendable with USB modules. You can install the module either outside the device or integrate it into the printer.

So that the module can neither be stolen nor damaged unhappily, we recommend to insert the module into the printer. This is very simple and is done very quickly.

1. Depending of the Device-Model you have to remove the Logic-board out the printer or open the unit to access the Formatter-Board. For details please read the device manual, which should show pictures like this example:



2. Push the USB-Module in a free USB-Slot as it is shown below and reinstall the formatter.



Push the USB-Modul in one of the free USB-Slots as it is shown above.

3. Further, you have to follow the description in the installation and programmer's guide.